



- 1 30 A Body control module battery power in feed 1.
- 3 30 A Body control module battery power in feed 2.
- 4 30 A Fuel pump.
- 6 25 A Powertrain control module power.
- 7 30 A Powertrain components.
- 8 20 A Powertrain components.
- 9 20 A Ignition coils.
- 13 40 A Blower motor.
- 16 10 A Rear windshield washer.
- 18 30 A Starter motor.
- 21 10 A Not used (spare).
- 22 10 A 360 degree camera module.
- 23 10 A Anti-lock brake system run start feed.
- 24 10 A Powertrain control module.Power steering module.
- 25 20 A Blind spot information system.Rear view camera.Adaptive cruise control.Driveline control module.
- 26 15 A Transmission control module.
- 28 60 A Anti-lock brake system valves.
- 29 60 A Anti-lock brake system pump.
- 30 30 A Driver power seat.
- 31 30 A Passenger power seat.
- 32 20 A Auxiliary power point.
- 33 20 A Auxiliary power point.
- 34-Not used.
- 36-Not used.
- 38 30 A Heated seat module.
- 39 15 A Vehicle dynamics control module (Raptor).
- 42 30 A Trailer brake control module.
- 44 10 A Brake on-off switch.
- 46 20 A SYNC module.
- 50 40 A Heated rear windshield.
- 54 40 A Driveline control module.
- 55 30 A Trailer tow park lamp relay.
- 58 20 A Trailer tow backup lamps.
- 60 30 A Upfitter switch #1 (Base).Upfitter switch #3 (Raptor).
- 61 15 A Upfitter switch #2.
- 62 10 A Upfitter switch #3 (Base).Upfitter switch #1 - off-road driving lights (Raptor).
- 63 10 A Upfitter switch #4.
- 64 10 A Upfitter switch #5.
- 65 10 A Upfitter switch #6.
- 66 10 A Stability bar disconnect module.
- 69 30 A Front windshield wiper.
- 71 30 A Rear windshield wiper.
- 80 10 A Integrated wheel end(Raptor).
- 91 40 A Trailer tow light module.
- 100 20 A Left-hand headlamps.
- 101 20 A Right-hand headlamps.
- 107 30 A Trailer tow battery charge.
- 120 10 A Fuel injectors (2.7L, Raptor).
- 124 5 A Not used (spare).
- 125 10 A USB smart charger 1.
- 139 5 A USB smart charger 2.
- 140 5 A Not used (spare).
- 141 5 A Not used (spare).
- 146 20 A amplifier.
- 158 10 A Stability bar disconnect module run/start.
- 160 10 A Smart data link control.
- 182 60 A Driver door module.
- 183 60 A Passenger door module.
- 202 60 A Body control module B+.
- 210 30 A Body control module start stop.



- 1-Not used.
- 2 10 A Power windows. DC/AC inverter. Upfitter switches.
- 3 7.5 A Exterior mirrors. Wireless charging module.
- 4 20 A Not used (spare).
- 5-Not used.
- 6-Not used.
- 7 10 A Not used.
- 8 5 A Not used (spare).
- 9 5 A Not used (spare).
- 10-Not used.
- 11-Not used.
- 12 7.5 A Climate control.Gateway module.
- 13 7.5 A Steering column control module. Instrumentclustermodule.
- 14 15 A Not used (spare).
- 15 15 A Not used (spare).
- 16-Not used.
- 17 7.5 A Not used (spare).
- 18 7.5 A Not used (spare).
- 19 5 A Ignition switch. Headlamps.
- 20 5 A Telematics modem.
- 21 5 AI n-vehicle temperature and humidity sensor.
- 22 5 A Not used.
- 23 30 A Not used (spare).
- 24 30 A Not used (spare).
- 25 20 A Not used (spare).
- 26 30 A Not used (spare).
- 27 30 A Not used (spare).
- 28 30 A Not used (spare).
- 29 15 A Not used (spare).
- 30-Not used.
- 31 10 A Terrain management switch. Integrated control panel switch.
Driveline and chassis controls switch panel
12 inch center display.
Radio frequency receiver module.
- 32 20 A Audio control module.
- 33-Not used.
- 34-Not used.
- 35 5 A Not used (spare).
- 36 15 A Automatic high beam.
Image processing module A.
- 37 20 A Auto-dimming interior
mirror.
Parking assist control
module.
Heated steering wheel.
- 38 30 A Circuit Breaker Not used.